

# **PROJECT BRIEF**

Chlor-Alkali Plant Improves Production Efficiency and Reliability with ADVANCED AMBERPACK™ Ion Exchange Technology

### **PROJECT OVERVIEW**

At a chlor-alkali plant in Charleston, TN, sodium chloride brine production depended on a reliable supply of high-purity feedwater. Leveraging ADVANCED AMBERPACK<sup>™</sup> deionization (ADI) technology, SAMCO delivered a high yield ion exchange (IX) system that optimized production efficiency.

### **OBJECTIVE**

Deionize blend of process condensate and municipal water to supply salt saturator feed for chloralkali product manufacturing.

 Reduce minerals to less than 5 micromhos per centimeter

### **SCOPE OF SERVICE**

SAMCO delivered a turnkey IX deionization system, with the project scope entailing a comprehensive process, mechanical, and electrical design and engineering, fabrication, commissioning, startup training and support.

#### **CHALLENGES**

- Low mineral concentration tolerance for electrochemical cells
- Integration with existing distributed control system (DCS)

#### SOLUTION

SAMCO delivered a 585 GPM IX system to provide a consistent source of high-purity feedwater to support the production of saturated sodium chloride brine. Leveraging ADI technology for maximum efficiency and reliability, SAMCO was able to cut production waste while producing sufficient purity for downstream electrochemical cells. The comprehensive system comprised three parallel IX trains, a backwash column for periodic resin regeneration, and peripherals. The system also included terminal boxes for optimal integration with customer-supplied DCS. To enable fast-track delivery and startup. SAMCO performed comprehensive design, fabrication, and installation of the prepackaged system.

#### **TECHNOLOGY**

SAMCO delivered a high yield ADI system, including:

- Parallel three-train IX pressure vessels
- Fractal-type internals
- Auxiliary filters
- Rinse and recycle pumps
- Chemical metering equipment
- DCS-ready terminal boxes

# **OVERVIEW**

Industry Chemical

**Location** Charleston, TN

# Objective

Deionize source water to <5 µ/cm for salt saturator feeds

# Solution

585 GPM Ion Exchange System

Looking to optimize source feed deionization processes? Is quality water an issue? Contact us today at www.SamcoTech.com • askengineers@samcotech.com • (716) 743 9000